

A CONTROLLER - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| A Controller Electrical Maintenance & Troubleshooting Reference | MREACON57E | 0 | \$119.00 |
| A Controller Electrical Schematics Vol. 1.0 <i>EX, ET, EG, EH & U series robots</i> | MRESACON123E1 | 0 | \$317.00 |
| A Controller Electrical Schematics Vol. 2.0 <i>EE10FA14, EE10FA11 robots</i> | MRESACON92E2 | 0 | \$317.00 |
| A Controller Electrical Schematics Vol. 3.0 <i>JS10 robots</i> | MRESACON123E3 | 0 | \$317.00 |
| A Controller Installation | MIACON101E | 0 | \$80.00 |

A CONTROLLER - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| A Controller Operations and Programming | MROACONTW112EN | 0 | \$80.00 |

A/AD CONTROLLER - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| A50 Electrical Schematics <i>JS5 robots, non-HQ</i> | MRESA50CON36E | 0 | \$317.00 |
| AD Controller (HQ) Electrical Schematics Vol. 1 <i>U, EH, Js30/40 robots</i> | MRESADHQCON57E1 | 0 | \$317.00 |
| AD Controller (HQ) Electrical Schematics Vol. 2 <i>Js5/6/10, JW5, JC5 robots</i> | MRESADHQCON67E2 | 0 | \$317.00 |
| AD Controller Electrical Maintenance & Troubleshooting Reference | MREADCON67E | 4 | \$119.00 |
| AD Controller Electrical Schematics Vol. 1 <i>UX,UT,UZ, EH, JS30/40 robots</i> | MRESADCON47E1 | 1 | \$317.00 |
| AD Controller Electrical Schematics Vol. 2 <i>JS5,JS6,JS10 and JW5 robots</i> | MRESADCON27E2 | 0 | \$317.00 |
| AD Controller Installation | MIADCON57E | 0 | \$80.00 |

A/AD CONTROLLER - MANUALS on CD

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| KRI Reference Manuals on CD Volume 1 <i>615 and A/AD Controller Manuals</i> | DPVV1V043E | 1 | \$96.00 |

A/AD CONTROLLER - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| A/AD Controller Operations & Programming Reference | MROA/ADCONTO57E | 2 | \$80.00 |
| AS Language Reference | MRPAS57E | 0 | \$119.00 |

A/AD CONTROLLER - OPTIONS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|----------------------------------|------------------|-----------------|----------------|
| A/AD Controller Sealing Function | 90210-1051DE | A | \$80.00 |

A/AD CONTROLLER - WELDING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| Arc Welding AS Language Reference | MRPARCAS128E | 1 | \$119.00 |
| Arc Welding Cells Operations and Installation | MROAMCW30E | 3 | \$80.00 |
| Arc Welding Operations and Programming Reference | MROARCJS17E | 1 | \$80.00 |

C CONTROLLER - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| C Controller Electrical Maintenance Reference Manual <i>includes EP type C controller</i> | MRECCON118E | 12 | \$119.00 |
| C Series Controller Electrical Schematics Vol. 1 <i>U series robots</i> | MRESCCON128E1 | 2 | \$317.00 |
| C Series Controller Electrical Schematics Vol. 2 <i>F series robots</i> | MRESCCON89E2 | 0 | \$317.00 |
| C Series Controller Electrical Schematics Vol. 3 <i>Z series robots</i> | MRESCCON80E3 | 1 | \$317.00 |
| C Series Controller Electrical Schematics Vol. 4 <i>KE610 and KF121 Robots</i> | MRESCCON43E4 | 0 | \$317.00 |
| C Series Controller Installation | MICCON38E | 4 | \$80.00 |
| C Series Controller Quick Reference Troubleshooting Guide | MRECCTSV112E | 2 | \$80.00 |
| C1/C2/C52/C70 External I/O Signal (Interlock Signal) | 90204-1004DE | C | \$80.00 |
| C3*/C4*/C70/C80 Controller External I/O Manual | 90204-1008DE | F | \$80.00 |
| C3/4/70/80 Controller Troubleshooting Manual | 90206-1023DE | D | \$119.00 |

C CONTROLLER - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| C Controller AS Language Reference Manual | MRPCCONTO118E | 2 | \$119.00 |
| C Series Controller Backup and Download Procedures | MROCCONTBKLD69E | 0 | \$80.00 |
| C Series Controller I/O Interface | MREICCON28E | 7 | \$80.00 |

| | | | |
|---|---------------|---|----------|
| C Series Controller Operations and Programming Reference Manual | MROCCONTO87E | 8 | \$80.00 |
| C Series Controller Software Download Procedures | MROCCONTSW78E | 4 | \$80.00 |
| KTMSOFT Installation and Operation | MROKTMSO99E | 0 | \$119.00 |

C CONTROLLER - OPTIONS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| 1HS Board Instruction Manual | 90210-1150DE | A | \$80.00 |
| Arm ID Board Instruction Manual | 90210-1142DE | A | \$80.00 |
| C Controller Arc Welding Thick Plate Option | 90210-1119DE | A | \$80.00 |
| C Controller Conveyor Synchronization Incremental Encoder Interface Board 1JS Hardware | 90210-1168DE | A | \$80.00 |
| C Controller Host Communication I | 90210-1080DE | A | \$80.00 |
| C Controller Laser Sensor Tacking and Adaptive Control Function Operation Manual | 90210-1135DE | A | \$80.00 |
| C Controller Mutual Wait and Gun Relative Distance Check Function | 90210-1165DE | B | \$80.00 |
| C Controller Synchronous Operation Manual | 90210-1129DE | A | \$80.00 |
| C Controller, Collision Detection Function | 90210-1134DE | C | \$80.00 |
| C Controller, TCP/IP Function Instruction Manual | 90210-1159DE | D | \$80.00 |
| C Series Controller Device Net Composite I/O Board Hardware Manual | 90210-1171DE | A | \$119.00 |
| C Series Controller External Axis Servo Parameter Setting Manual | 90210-1130DE | A | \$0.00 |
| C Series Floppy Disk Drive Option | 90210-1117DE | B | \$80.00 |
| C Series Separate Control Setting Instructions | 90210-1148DE | A | \$80.00 |
| C Series, Failure Prediction Function for Reduction Gear | 90210-1151DE | A | \$80.00 |
| C Series, Flow Rate Control Instruction Manual | 90210-1115DE | A | \$80.00 |

| | | | |
|---|--------------|---|---------|
| Data Storage Function Operation | 90210-1139DE | A | \$80.00 |
| Relative Data Output for Flowrate Control | 90210-1128DE | A | \$80.00 |
| Soft Absorber Function, Option I | 90210-1082DE | 0 | \$80.00 |

C CONTROLLER - WELDING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| C Controller Arc Welding AS Language Manual | MRPCARCW60E | 0a | \$119.00 |
| C Controller Arc Welding Operations and Programming | MROCARCW20E | 0 | \$80.00 |
| C Controller Servo Weld Gun Instruction Manual (Type C) | 90210-1153DE | B | \$80.00 |
| C Series Controller Servo Spot Weld Gun Set Up and Operation Manual | MRVCCSGW31E | 6 | \$80.00 |

C5* CONTROLLER - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| C50E/C52E Controller, Explosion-Proof Type, Installation & Connection Manual | 90202-1075DE | B | \$80.00 |
| C50E/C52E TROUBLESHOOTING MANUAL | 90206-1038DE | C | \$119.00 |
| C52* Controller Electrical Maintenance | MREC5292E | 1 | \$119.00 |
| C52* Controller Electrical Schematics <i>UX and UB150 robots</i> | MRESC52BV902E | 2 | \$317.00 |
| C52* Controller Quick Reference Troubleshooting Guide | MREC52TSV23E | 1 | \$80.00 |

C5* CONTROLLER - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| C5* Operation & Maintenance Manual, Toyota Specification, Servo Spot Weld Gun <i>Includes Reference Manuals on CD Vol. 3</i> | MRVSWG11E | 2 | \$119.00 |
| C5* Operation and Maintenance Manual, Toyota Specification, Matehan <i>Includes Reference Manuals on CD Vol. 3</i> | MRVC52M64E | 0 | \$119.00 |
| C50E/C52E CONTROLLER OPERATION MANUAL, STANDARDIZED TP VERSION | 90203-1100DE | A | \$80.00 |
| C52 Controller Operations and Programming Manual | MROC52W51E | 0 | \$80.00 |

C5* CONTROLLER - OPTIONS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| Toyota Motor Corporation, Maintenance Support Function (TP Version) Instruction Manual | 90210-1154DE | A | \$80.00 |

C5* CONTROLLER - WELDING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| C52 Controller Servo (Spot) Weld Gun Set Up and Operation | MRVTSGW41E | 0 | \$80.00 |
| C52 Controller Servo Arc Welding Operations and Programming Reference | MROCSAW72E | 0 | \$80.00 |

C52 CONTROLLER - MANUALS on CD

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| KRI Reference Manuals on CD Volume 3-Toyota Specific <i>Toyota Specification Manuals</i> | DPVT3V043E | 1 | \$96.00 |

CBT (Computer Based Training) - C CONTROLLER

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| C Controller Operations & Programming CBT | CCBTCCONO59E | 0 | \$900.00 |

C-EP CONTROLLER - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| C3/C4/C70/C80 Installation and Connection Manual | 90202-1031DE | G | \$119.00 |

C-EP CONTROLLER - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| C Series Controller, EP Type, Operations and Programming Manual | MROEPCCP121E | 1 | \$80.00 |

C-EP CONTROLLER - OPTIONS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| C35/C45/C55 Explosion-Proof Type Controller, Paint Supply Equipment Control Hardware M | 90210-1169DE | A | \$80.00 |

D CONTROLLER - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| D Controller Electrical Schematics Manual, Vol. 1.0 | MRESDCON84E1 | 0 | \$317.00 |
| D Controller Electrical Schematics Manual, Vol. 2.0 | MRESDCON94E2 | 0 | \$317.00 |
| D Controller Electrical Schematics Manual, Vol. 3.0 | MRESDCON94E3 | 0 | \$317.00 |
| D Series Controller Electrical Maintenance <i>Includes D Cont. Error Codes manual MRVDCONTV113E (no additional charge)</i> | MREDCON15E | 1 | \$119.00 |
| D Series Installation and Connection Manual | MRIDCONV34E | 5 | \$80.00 |
| D7x Series Controller Installation and Connection Manual | MRID7XV86E | 2 | \$80.00 |

D CONTROLLER - MANUALS on CD

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|-----------------------|------------------|-----------------|----------------|
|-----------------------|------------------|-----------------|----------------|

| | | | |
|--|---------------|---|---------|
| D Controller Options Manuals on CD | DDODOPT85E | 1 | \$96.00 |
| D Series Controller Electrical Schematics on CD | DDES DV45E | 1 | \$96.00 |
| F Series / D Controller Arc Welding Reference Manuals on CD | DDVFDARC15E | 0 | \$96.00 |
| FS03-FS06-FS10-D76/D77 Controller Reference Manuals on CD | DDVFS6D77V86E | 3 | \$96.00 |
| FS06-FS60/D Controller Reference Manuals on CD | DDVFS6DV84E | 3 | \$96.00 |
| M Series/D Controller Reference Manuals on CD | DDVMDV84E | 3 | \$96.00 |
| ZZ Series / D Controller Arc Welding Reference Manuals on CD | DDVZZDARCW15E | 1 | \$96.00 |
| ZZ Series/D Controller Reference Manuals on CD | DDVZZDV84E | 3 | \$96.00 |

D CONTROLLER - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| D Series Controller Arc Welding Operation | 90203-1085DE | B | \$80.00 |
| D Series Controller AS Language Reference Manual | MRPDCONTO63E | 0 | \$119.00 |
| D Series Controller I/O Interface Manual | MREIDCON125E | 0 | \$80.00 |
| D Series Controller Operations and Programming Manual <i>Includes D Cont. Error Codes manual MRVDCONTV113E (no additional charge)</i> | MRODCONTO43E | 5 | \$119.00 |
| D Series External I/O Manual | 90204-1021DE | D | \$0.00 |

D CONTROLLER - OPTIONS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| Analog Input Instruction Manual | 90210-1176DE | A | \$80.00 |
| Arm ID Board Instruction Manual | 90210-1174DE | A | \$80.00 |
| Collision Detection for D Controller | 90210-1182DE | A | \$80.00 |
| Conveyor Synchronous Operation | 90210-1199DE | A | \$80.00 |
| D Controller General FieldBus I/O Usage Manual | 90210-1184DE | C | \$80.00 |

| | | | |
|--|---------------|---|---------|
| D Controller Servo System Gain Change Function | 90210-1175DEB | 0 | \$80.00 |
| D Series Built-In Vision System, General Reference Guide | 90210-1183DE | A | \$80.00 |
| D Series, 1HS Board Instruction Manual | 90210-1180DE | A | \$80.00 |
| Failure Prediction Function for Reduction Gear | 90210-1188DE | A | \$80.00 |
| Flow Rate Control Operation | 90210-1203DE | A | \$80.00 |
| Friction Spot Joining Gun Operation | 90210-1223DE | A | \$80.00 |
| Host Communication I | 90210-1177DE | A | \$80.00 |
| Klogic/Kladder Operation Manual | 90210-1186DE | D | \$80.00 |
| Motion Based on Fixed Tool | 90210-1179DE | A | \$80.00 |
| Sensing Function | 90210-1196DE | A | \$80.00 |
| Signal Output within Path Function | 90210-1222DE | A | \$80.00 |
| Simple Palletizing Function | 90210-1237DE | A | \$80.00 |
| Soft Absorber Function | 90210-1178DE | C | \$80.00 |
| Spin Control Function | 90210-1181DE | A | \$80.00 |
| Taught Program Protection Function | 90210-1215DE | A | \$80.00 |
| TCP/IP Communication | 90210-1190DE | A | \$80.00 |
| Voice Recorder Function | 90210-1221DE | A | \$80.00 |

D CONTROLLER - WELDING APPLICATIONS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| D Series Arc Welding Thick Plate Option Operation | 90210-1210DE | A | \$80.00 |
| D Series Controller Arc Welding AS Language Reference Manual | 90209-1018DE | C | \$119.00 |

| | | | |
|--|--------------|---|---------|
| D Series Controller Servo Weld Gun Instruction Manual | 90210-1185DE | A | \$80.00 |
| D Series Controller Servo Weld Gun Instruction Manual (FORD) | MRVDCSGW46E | 0 | \$80.00 |

E SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|----------------------|-----------------|----------------|
| EA65/EA100 Electrical/Mechanical Maintenance | MRMEEA65/100W99E | 0 | \$119.00 |
| EE10 Mechanical Maintenance Manual | MRMEE1023E | 0 | \$119.00 |
| EE10-A77 Electrical Maintenance Manual | MREEE10A77P98E | 0 | \$119.00 |
| EE10F/G Mechanical Parts | MRMPEE10P32E | 0 | \$80.00 |
| EH100/120 Maintenance Manual | MRMEEH120W73E | 0 | \$119.00 |
| EH100/EH120 Mechanical Parts | MRMPEH100/EH120W31E | 0 | \$80.00 |
| EH120A002-A Mechanical Parts | MRMPEH120A002-A63E | 0 | \$80.00 |
| EH120A002-B Mechanical Parts | MRMPEH120A002-B63E | 0 | \$80.00 |
| EH120F Mechanical Maintenance | MRMEH120W83E | 0 | \$119.00 |
| EH120F6AB Electrical Maintenance & Troubleshooting | MREEH120F6ABW44E | 0 | \$119.00 |
| ES50 Electrical/Mechanical Maintenance | MRMEES50W99E | 0 | \$119.00 |
| ES65 Electrical Maintenance & Troubleshooting Reference | MREES65W70E | 0 | \$119.00 |
| ES65 Mechanical Parts | MRMPES65W11E | 0 | \$80.00 |
| ET100F655-L12 Shelf-Mount Mechanical Parts | MRMPET100F655L12W41E | 0 | \$80.00 |
| ET120-B Shelf Mount Mechanical Parts | MRMPET120-BW93E | 0 | \$80.00 |
| EX100 Electrical Maintenance and Troubleshooting | MREEX100W118E | 0 | \$119.00 |
| EX100 Electrical Parts | MREPEX100W118E | 0 | \$80.00 |

| | | | |
|---|---------------------|---|----------|
| EX100 Electrical Schematics | MRESEX100W88E | 0 | \$317.00 |
| EX100 Mechanical Maintenance | MRMEX100W69E | 0 | \$119.00 |
| EX100 Mechanical Parts | MRMPEX100W39E | 0 | \$80.00 |
| EX100F615 Installation | MIEX100W99E | 0 | \$80.00 |
| EX100F616 Electrical/Mechanical Maintenance | MREMEX100W128E | 0 | \$119.00 |
| EX100G Mechanical Parts | MRMPEX100GW80E | 0 | \$80.00 |
| EX100G Preventative Maintenance | MRMEX100GW129E | 0 | \$119.00 |
| EX120F Mechanical Maintenance | MRMEX120W32E | 0 | \$119.00 |
| EX120F Mechanical Parts | MRMPEX120W80E | 0 | \$80.00 |
| EX120G/150G Mechanical Parts | MRMPEX120G/150GW80E | 0 | \$80.00 |
| EX150-B Mechanical Parts | MRMPEX150-BW80E | 0 | \$80.00 |
| EX200 Mechanical Parts | MRMPEX200W80E | 0 | \$80.00 |

E SERIES - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|-------------------|-----------------|----------------|
| EE10 Operations, Programming & Maintenance | MROPMEE10P41E | 0 | \$119.00 |
| EE10/JS10 Operation & Programming Training Reference | MROPEE10/JS10W49E | 0 | \$80.00 |
| EF10 Vision System Operations & Maintenance | MROME10V12E | 0 | \$119.00 |
| EF10F/G317 Operations, Programming , & Maintenance | MROME10S49E | 0 | \$80.00 |
| EH120 Operations/Electrical & Mechanical Maintenance | MREH12042E | 0 | \$119.00 |
| EH120 Operations/Maintenance/Parts/RoutineMaintenance | MROMEH120W71E | 0 | \$119.00 |
| EH120F6AB Operations & Programming | MROEH120F6ABW34 | 0 | \$80.00 |

| | | | |
|--|------------------|---|----------|
| ES65 Operations & Programming Reference | MROES65W60E | 0 | \$80.00 |
| EX100 Operations and Programming Reference | MROEX100W68E | 0 | \$80.00 |
| EX40/FA10/EX30FA16 Reference | MREX40/EX30MH92E | 0 | \$158.40 |

F SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|-------------------|-----------------|----------------|
| FS006L-A002 Mechanical Parts | MRMPFS06LV40E | 0 | \$80.00 |
| FS006L-B002 Mechanical Parts | MRMPFS06LBV60E | 0 | \$80.00 |
| FS006N-A002 Mechanical Parts | MRMPFS06NV40E | 0 | \$80.00 |
| FS010C-A002 Mechanical Parts | MRMPFS10CV40E | 0 | \$80.00 |
| FS010E-A002 Mechanical Parts | MRMPFS10EV40E | 0 | \$80.00 |
| FS010L-A002 Mechanical Parts | MRMPFS10LV50E | 0 | \$80.00 |
| FS020C-A002 Mechanical Parts | MRMPFS20CV50E | 0 | \$80.00 |
| FS020N-A002 Mechanical Parts | MRMPFS20NV50E | 0 | \$80.00 |
| FS030L-A002 Mechanical Parts | MRMPFS30LV50E | 0 | \$80.00 |
| FS030N/045C-B002 Mechanical Parts | MRMPFS30N45CBV60E | 0 | \$80.00 |
| FS030N/FS045C-A002 Mechanical Parts | MRMPFS30N/45CV50E | 0 | \$80.00 |
| FS045N-A002 Mechanical Parts | MRMPFS45NV50E | 0 | \$80.00 |
| FS045N-B002 Mechanical Parts Manual | MRMPFS45NBV60E | 0 | \$80.00 |
| FS06-FS10C,E Robot Mechanical Maintenance Manual | MRMFS06V51E | 1 | \$119.00 |
| FS06N-B002 Mechanical Parts | MRMPFS06NBV60E | 0 | \$80.00 |
| FS10C-B002 Mechanical Parts | MRMPFS10CBV60E | 0 | \$80.00 |

| | | | |
|--|----------------|---|----------|
| FS10E-B002 Mechanical Parts | MRMPFS10EBV60E | 0 | \$80.00 |
| FS10L-B002 Mechanical Parts | MRMPFS10LBV60E | 0 | \$80.00 |
| FS10L-FS20 Mechanical Maintenance Manual | MRMFS20V91E | 1 | \$119.00 |
| FS10N-A002 Mechanical Parts | MRMPFS10NV30E | 0 | \$80.00 |
| FS10N-B002 Mechanical Parts | MRMPFS10NBV60E | 0 | \$80.00 |
| FS20C-B002 Mechanical Parts | MRMPFS20CBV60E | 0 | \$80.00 |
| FS20N-B002 Mechanical Parts | MRMPFS20NBV60E | 0 | \$80.00 |
| FS30-FS45 Mechanical Maintenance Manual | MRMFS45V61E | 1 | \$119.00 |
| FS30L-B002 Mechanical Parts | MRMPFS30LBV60E | 0 | \$80.00 |

J SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|---------------------|-----------------|----------------|
| JE30 Mechanical Maintenance | MRMJE30P30E | 1 | \$119.00 |
| JE30 Mechanical Parts Manual | MRMPJE30P30E | 1 | \$80.00 |
| JS10 Mechanical Maintenance | MRMJS1057E | 0 | \$119.00 |
| JS10 Mechanical Parts | MRMPJS1022E | 0 | \$80.00 |
| JS10-A002 Mechanical Parts | MRMPJS10A002W26E | 0 | \$80.00 |
| JS30/40 A003 Mechanical Parts | MRMPJS30/40A003W44E | 0 | \$80.00 |
| JS30/40 A005 (HQ Version) Mechanical Parts | MRMPJS30/40HQ116E | 0 | \$80.00 |
| JS5 Mechanical Maintenance | MRMJS557E | 1 | \$119.00 |
| JS5-A001 Mechanical Parts | MRMPJS5A001W115E | 0 | \$80.00 |
| JS5-E001 HQ Version Mechanical Parts | MRMPJS5HQ48E | 1 | \$80.00 |

| | | | |
|----------------------------|-----------------|---|----------|
| JS6 Mechanical Maintenance | MRMJS615E | 0 | \$119.00 |
| JS6 Mechanical Parts | MRMPJS625E | 0 | \$80.00 |
| JS6-A002 Mechanical Parts | MRMPJS6A002W26E | 0 | \$80.00 |

J SERIES - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| JS10 Operations and Programming Reference | MROMJS10A09W50E | 0 | \$80.00 |
| JS10 Operations and Programming Reference | MROJS10O52E | 0 | \$80.00 |

K SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| KE610 Robot Mechanical Maintenance Manual | MRMKE610P72E | 0 | \$119.00 |
| KE610-L, H Installation and Connection | MRIKE610P44E | 0 | \$80.00 |
| KF121 Robot Mechanical Maintenance Manual | MRMKF121P42E | 2 | \$119.00 |
| KT254&264 Zeroing and Motor Replacement Manual | 90213-1036DE | A | \$119.00 |
| KT254/264 Installation & Connection Robot Arm | 90202-1089DE | B | \$80.00 |

KOBELCO MANUALS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| KRC-A-12.2 Electrical Maintenance | MREP122P60E | 0 | \$119.00 |
| KRC-A-12.3 - NUMMI Electrical Maintenance | MREP123P60E | 0 | \$119.00 |
| KRC-A-P07 Electrical Maintenance | MREP07P60E | 0 | \$119.00 |
| KRC-A-P17 Electrical Maintenance | MREP17P60E | 0 | \$119.00 |
| KRC-A-P18 Electrical Maintenance | MREP18P60E | 0 | \$119.00 |
| KRC-A-P21/P24 Electrical Maintenance | MREP21P60E | 0 | \$119.00 |
| KRE320 Series Mechanical Maintenance | MRM320P60E | 0 | \$119.00 |
| KRE320-L Series Mechanical Maintenance | MRM320LP60E | 0 | \$119.00 |

| | | | |
|---|--------------|---|----------|
| KRE400 Series, Type G9, Electrical Maintenance | MRE400G9P60E | 0 | \$119.00 |
| KRE400 Series, Type G9, Operation and Programming | MRPG9P60E | 0 | \$80.00 |
| KRE410-G Series Mechanical Maintenance | MRM410GP60E | 0 | \$119.00 |
| KRE443-S, L Series Mechanical Maintenance | MRM443SLP60E | 0 | \$119.00 |
| KRE453 Series Mechanical Maintenance | MRM453P60E | 0 | \$119.00 |
| KRE453 Series Mechanical Maintenance | MRM453TP60E | 0 | \$119.00 |
| KRE454 Series Mechanical Maintenance | MRM454P60E | 0 | \$119.00 |
| KRE454 Series Mechanical Maintenance | MRM454TP60E | 0 | \$119.00 |
| P-V2.0 Version Operation and Programming | MRPV20P60E | 0 | \$80.00 |
| P-V2.1 Version Operation and Programming | MRPV21P60E | 0 | \$80.00 |
| P-V2.2 Version - TMMI/NUMMI Operation & Programming | MRPV22TP60E | 0 | \$80.00 |
| P-V2.2 Version Operation and Programming | MRPV22P60E | 0 | \$80.00 |
| P-V2.3 Version - TMMI/NUMMI Operation & Programming | MRPV23TP60E | 0 | \$80.00 |
| P-V2.3 Version Operation and Programming | MRPV23P60E | 0 | \$80.00 |
| P-V2.3 Version Operation and Programming | MRPTVERP60E | 0 | \$80.00 |

MANUALS on CD - C CONTROLLER

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| C Series Controller Electrical Schematics on CD <i>Contains Vol 1, Vol 2, and Vol. 3 C Controller Electrical Schematics</i> | DPESV044E | 1 | \$96.00 |
| K Series/C Controller (EP Type) Reference Manuals on CD | DDVKCV84E | 2 | \$96.00 |
| KRI Reference Manuals on CD Volume 2 <i>C Controller Manuals</i> | DPVC2V043E | 1 | \$96.00 |
| KT264 C50/52E Reference Manuals on CD | DDVKTV96E | 1 | \$96.00 |

MISC MANUALS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| Brake Slip Test Set Up and Operation | MROBRKSLPV12E | 0 | \$80.00 |
| IPEAKLOG Operation Guide | MROIPEAK92E | 0 | \$80.00 |
| Kawasaki Data Conversion Software | MROKDCS82E | 0 | \$80.00 |
| Kawasaki Robot Slogic Translator Software & User's Manual | MRASLOGICO66E | 0 | \$1,200.00 |
| Pocket Guide - AS Language Keywords (AD, C and D Controller) | H-OS-AS_KYWD | 2 | \$12.00 |
| Pocket Guide - AS Language Keywords (AD, C and D Controller) | H-OS-AS_KYWD | 1 | \$12.00 |

P260/P760/PA761 MANUALS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---------------------------------|------------------|-----------------|----------------|
| P260 Supplemental Manual | MRP260MH69E | 0 | \$80.00 |
| P760HS Electrical Maintenance | MREP760HSSM10E | 0 | \$119.00 |
| P760HS Mechanical Maintenance | MRMP760HSSM20E | 0 | \$119.00 |
| P760HS Operations & Programming | MROP760HSS23E | 0 | \$80.00 |
| PA761 Operations & Programming | MROPA761W89E | 0 | \$80.00 |

S SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| UB150 Robot Mechanical Maintenance Manual | MRMUBV62E | 1 | \$119.00 |

S5* CONTROLLER - MANUALS on CD

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|------------------------------------|------------------|-----------------|----------------|
| S51 / S52 Controller Manuals on CD | DDVS52V85E | 1 | \$96.00 |

SR SERIES - MANUALS on CD

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---------------------------------------|------------------|-----------------|----------------|
| SR Series/ S Controller Manuals on CD | DDVSRV95E | 1 | \$96.00 |

TRAVERSE UNITS

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| Traverse Unit (Tube-Style) Installation and Maintenance Manual | MRITRVT63E | 1 | \$80.00 |

| | | | |
|---|------------|---|---------|
| Traverse Unit Installation and Maintenance Manual | MRITRAV11E | 3 | \$80.00 |
|---|------------|---|---------|

UD SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| UD100-C001 HQ Version Mechanical Parts | MRMPUD100HQ18E | 1 | \$80.00 |
| UD150-C001 HQ Version Mechanical Parts | MRMPUD150HQ48E | 0 | \$80.00 |

UD SERIES - OPERATION AND PROGRAMMING

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| UD Operations and Programming Reference | MROUDM57E | 0 | \$80.00 |

UX SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|---------------------|-----------------|----------------|
| UT100/120/150 HQ Version Mechanical Maintenance | MRMUTHQ10067E | 1 | \$119.00 |
| UT100/120/150 Mechanical Maintenance | MRMUT10057E | 1 | \$119.00 |
| UT120 Mechanical Parts | MRMPUT120W104E | 0 | \$80.00 |
| UT120-A004 Mechanical Parts | MRMPUT120A004W105E | 0 | \$80.00 |
| UT120-A902 Mechanical Parts | MRMPUT120A902W95E | 1 | \$80.00 |
| UT120-C921 (HQ) Mechanical Parts | MRMPUT120C921HQ116E | 0 | \$80.00 |
| UT150-A003 Mechanical Parts | MRMPUT150A003W105E | 0 | \$80.00 |
| UT150-A902 Mechanical Parts | MRMPUT150A902W95E | 0 | \$80.00 |
| UT150-B921 HQ Version Mechanical Parts | MRMPUT150HQ28E | 0 | \$80.00 |
| UX100/120/150 HQ Version Mechanical Maintenance | MRMUXHQ10067E | 2 | \$119.00 |
| UX100/120/150 Mechanical Maintenance | MRMUX10057E | 1 | \$119.00 |
| UX120-A002 Mechanical Parts | MRMPUX120A002W104E | 1 | \$80.00 |
| UX120-A902 Mechanical Parts | MRMPUX120A902W55E | 0 | \$80.00 |
| UX120-E921 (HQ Version) Mechanical Parts | MRMPUX120E921HQ106E | 0 | \$80.00 |

(Hard Copy/Bound Documents)

| | | | |
|--|---------------------|---|----------|
| UX150-A004 Mechanical Parts | MRMPUX150A004W95E | 0 | \$80.00 |
| UX150-A902 Mechanical Parts | MRMPUX150A902W37E | 0 | \$80.00 |
| UX150-C921 HQ Mechanical Parts | MRMPUX150C921HQ98E | 0 | \$80.00 |
| UX200-A902 Mechanical Parts | MRMPUX200A902W85E | 0 | \$80.00 |
| UX200-D921 (HQ Version) Mechanical Parts | MRMPUX200D921HQ116E | 0 | \$80.00 |
| UX300 HQ Mechanical Parts Manual | MRMPUX300V80E | 1 | \$80.00 |
| UX300 Mechanical Maintenance | MRMUX300V120E | 1 | \$119.00 |

UZ SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|--------------------|-----------------|----------------|
| UZ100 Mechanical Parts | MRMPUZ100W53E | 0 | \$80.00 |
| UZ100/120/150 HQ Version Mechanical Maintenance | MRMUZHQ10067E | 1 | \$119.00 |
| UZ100/120/150 Mechanical Maintenance | MRMUZ10057E | 1 | \$119.00 |
| UZ120-A004 Mechanical Parts | MRMPUZ120A004W125E | 0 | \$80.00 |
| UZ120-A901 Mechanical Parts | MRMPUZ120A901W75E | 0 | \$80.00 |
| UZ120-C921 HQ Version Mechanical Parts | MRMPUZ120C921HQ27E | 0 | \$80.00 |

Z SERIES - INSTALLATION AND MAINTENANCE - Z SERIES

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| Z Series Zone LS Installation Manual | MRIZLSV71E | 2 | \$80.00 |
| ZZT/ZZX Robot Zone Limit Switch Installation Manual | MRIZZV15E | 0 | \$80.00 |

ZD SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| ZD130S/250S Robot Mechanical Maintenance Manual | MRMZD1V13E | 1 | \$119.00 |

ZT SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| ZT130U/165U/200U Mechanical Maintenance Manual | MRMZT1V101E | 3 | \$119.00 |

ZX SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|---|------------------|-----------------|----------------|
| Z Series Options Installation | MRIZV71E | 2 | \$80.00 |
| ZX130/165 Robot Mechanical Maintenance Manual | MRMZ1V60E | 4 | \$119.00 |
| ZX165U-A901 Mechanical Parts | MRMPZX165UV40E | 0 | \$80.00 |
| ZX300 Robot Mechanical Maintenance Manual | MRMZ3V102E | 1 | \$119.00 |

ZZ SERIES - INSTALLATION AND MAINTENANCE

| <u>Document Title</u> | <u>Stock No.</u> | <u>Rev. No.</u> | <u>Price *</u> |
|--|------------------|-----------------|----------------|
| ZZT130/165 Robot Mechanical Maintenance Manual | MRMZT1V125E | 1 | \$119.00 |
| ZZT200 Robot Mechanical Maintenance | MRMZT2V125E | 1 | \$119.00 |
| ZZX130/165 Robot Mechanical Maintenance Manual | MRMZ1V65E | 2 | \$119.00 |
| ZZX200 Robot Mechanical Maintenance Manual | MRMZ2V95E | 1 | \$0.00 |
| ZZX300 Robot Mechanical Maintenance Manual | MRMZ3V125E | 1 | \$119.00 |